

**WARNING:**  
INSTALL PRODUCT IN ACCORDANCE  
WITH LOCAL AND NATIONAL ELECTRICAL  
CODES; BY A QUALIFIED ELECTRICIAN.

**WARNING:**  
FAILURE TO COMPLY WITH THE  
INSTALLATION INSTRUCTIONS MAY  
RESULT IN DEATH OR SERIOUS INJURY.

**WARNING:**  
READ ALL SAFETY INSTRUCTIONS  
INCLUDED WITH LUMINAIRE BEFORE  
INSTALLING LUMINAIRE. SAVE  
INSTRUCTIONS FOR FUTURE USE.

**CAUTION:**  
THIS IS AN ELECTRONIC DEVICE. CARE MUST BE TAKEN  
DURING STORAGE AND HANDLING. STORE IN A CLEAN, COOL  
AND DRY LOCATION. ELECTROSTATIC DISCHARGE (ESD) CAN  
HARM THIS PRODUCT. AVOID STATIC DISCHARGE WHILE  
HANDLING THIS PRODUCT.

**CAUTION:**  
INTER-LUX IS NOT RESPONSIBLE FOR THE  
STRUCTURAL INTEGRITY OF THE BUILDING TO  
SUPPORT THE LUMINAIRE. ADDITIONAL BACKING  
MAY BE REQUIRED.

ISOMETRIC VIEW

PACKAGE INCLUDES:

(A) Housing  
Light Engine

(B) Regressed  
Cone, Flush  
Diffuser, or Wall  
Wash Cover

(C) Driver Box

ITEMS NEEDED (SUPPLIED BY OTHERS):

Phillips Head  
#1 Screwdriver

Wire Connectors

Wire Strippers

Ø 2 - 3/4" Hole Saw

MOUNTING DIMENSIONS

MOUNTING OPTIONS

DIFFUSER OPTIONS

Regressed Cone

Flush Diffuser

Wall Wash Cover

**TURN OFF MAIN POWER BEFORE PROCEEDING!**

Step 1: Install the Remote Driver(s) (C). Then run the  
low voltage wires from your driver to the desired  
location of your fixture.

**MOUNTING INSTALLATION STEPS**

Step 2: Cut Hole in the Ceiling and clear  
insulation as shown.  
(1" Maximum Ceiling Thickness)

Bottom View

Ø 2 - 3/4"

Side View

Step 3: Locate the Low Voltage leads from Driver (C)  
and pull them through the ceiling hole. Then make  
connection between the Housing (A) and the low  
voltage wires with provided connectors.

Step 4: Insert Housing (A) into ceiling hole (1) and tighten  
the outer screws until Housing (A) is secure (2).

Step 5: Align the springs on the Cover (B) with the  
corresponding slots on the Housing (A). Then insert  
the Cover (B) into the Housing (A) and ensure the  
Spring Clips (B) engage. Do not touch the lens  
when inserting (shown below). Finally, power and  
test for proper operation.

**Servicing Instructions:**

Cone Removal:  
To remove the cone cover (B), push the  
diffuser up and pull down on the inside lip of  
the cone. A hook tool or small screwdriver  
may be necessary to pull the cone out.

Flush Diffuser Removal:  
To remove the flush diffuser, we  
recommend using a suction cup  
(supplied by others) to grip the diffuser  
and pulling down until it is free.

Wall Wash:  
To remove the Wall  
Wash cone, pinch  
the lip with two  
fingers and pull  
down.

Gasket Application:  
The lens is supplied with a gasket on it. If  
this gasket is removed it must be  
reapplied before putting the lens back  
into the cone. Ensure that the inner slope  
of the gasket faces the dome of the lens.

Ceiling Thickness Key				
Material	Wood	Gypsum	Metal	Tile
Minimum	1/4"	1/2"	1/16"	1/2"
Maximum	1"	1"	1"	1"

inter•lux

410-381-1497

inter-lux.com

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF inter-lux. ANY REPRODUCTION  
IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF inter-lux IS PROHIBITED.

Page 1 of 2


DRAWING NOT TO SCALE

940-GDL-RD


REV N/C

\*Inter-lux reserves the right to make changes to this product and related installation instructions at any time without prior notice.

Wiring Key



Driver Wiring Diagrams



**NOTE: ALL SHOWN DRIVERS ARE INTER-LUX PROVIDED. FOR NON INTER-LUX PROVIDED DRIVERS PLEASE REFER TO DRIVER MANUFACTURERS. THE USE OF NON INTER-LUX PROVIDED DRIVERS VOIDS PRODUCT WARRANTY.**